


AIRIUS MOUNTING GUIDELINES - Wall Mount - Models 10, 15 & 25 (Long & Short Nozzle)

SOLD SEPERATELY

PUREAIR PHI SERIES


Unistrut or Ceiling Beam



230 V Plug
(single phase)

5-Core Fan Motor & PHI Power Cable
300 VAC Rated Cord Furnished 1.2m (4ft)

(Can be controlled by an On/Off switch
or Airius Speed Controller)



Wiring Diagram


Wall Mount must be installed using appropriate fixings for surface (Not supplied)

FOR BEST EFFICIENCY the Airius PureAir Destratification Fan should be securely installed as close as possible to the ceiling. The Airius air column should have an unobstructed passage to the floor. The Airius unit should not be mounted directly in front of heat ducts, vents or near any high heat source.

Airius Wall Mount

Airius PureAir PHI Air & Surface Purification Fan

Dimensions



AIRIUS MOUNTING GUIDELINES - Wall Mount - Models 10, 15 & 25 - Angled (Long & Short Nozzle)

SOLD SEPERATELY

PUREAIR PHI SERIES

Unistrut or Ceiling Beam

